



CAUTION: NEVER OVERLOAD ONE SIDE OF GUARDRAIL TRUCK CAUSING IT TO TIP. ALWAYS BALANCE THE LOAD EQUALLY FROM SIDE TO SIDE.

NEST GUARDRAILS FOR MAXIMUM STORAGE.

1 SECURE CASTER BEAMS TO FRAME WITH NUTS AND BOLTS. BOLT FACES DOWN.

2 POSITION ARM WELDMENT OVER TOP TUBE, POSITION PLATE UNDER TOP TUBE AND SECURE WITH NUTS AND BOLTS

3 IF EXTENSION ARMS ARE REQUIRED, REMOVE NUT & BOLT, SLIP EXTENSION ARM OUT AND REPLACE NUT & BOLT.

NOTE:
 THE ASSEMBLY PROCEEDURE FOR THE GUARDRAIL CADDY AND THE COMBINATION CADDY IS THE SAME, AND BOTH USE THIS INSTRUCTION SHEET.

A	ADDED NOTE	CAN 11/5/93
REVISION		

SICO INCORPORATED		DATE
COPYRIGHT 1992		09/29/92
TOLERANCES UNLESS OTHERWISE NOTED:		DRAWN BY
FRACTIONS ± 1/32	.XX ± .030	RGS
ANGLES ± 1°	.XXX ± .010	SCALE
DIMENSIONS ARE IN INCHES AND [MM'S]		1=20
ASSEMBLY INSTRUCTIONS		DWG FILE
109031		MAN_PART
FINISH	U/M	SHEET
N/A	PC	1 of 1