



# FOOD WARMER

Model No. 3918-500 (120V)

Model No. 3918-600 (240V)

Ref.	Part No.	Description	Qty
1	112920	Box, less door, with handles & latch.....	1
2	109502	Door.....	1
3	109501-05	Rivet, pop, 1/8" dia., 1/8" grip.....	11
4	112922	Shelf.....	1
5	112924	Latch.....	1
6	109505-08	Rivet, pop, 5/32" dia., 3/16" grip.....	4
7	108352-03	Handle, side.....	2
9	108352-01	Handle, top.....	1
11	109501-04	Cover, element.....	1
14	108274-100	Element, 120V.....	1
14	108274-200	Element, 240V.....	1
18	109500-02	Thermostat.....	1
21	109500-10	Screw, Phillips sheet-metal, #8 x 3/8".....	4
22	109500-300	Panel assembly, back, 120V (complete with element, etc.).....	1
22	109500-400	Panel assembly, back, 240V (complete with element, etc.).....	1
23	110079	Plug/switch combination.....	1
24	110078	Holder, fuse.....	1
25	109500-07	Fuse, 250V 3A, GMA 5 x 20 mm.....	1
26	112921	Screw, Phillips, 10-24 x 1-1/4".....	8
27	112923	Washer, #10.....	9
28	108278	Cord, power (120V Warmer).....	1
28	109519	Cord, power (240V Warmer).....	1
29	110076	Screw, machine, 10-24 x 1/2".....	5
30	110070	Nut, 10-24.....	1
31	110073	Screw, machine, 6-32 x 1/2".....	2
32	110072	Nut, hex, 6-32.....	2
33	110071	Washer, lock, #6.....	2
34	110075	Housing, switch/fuse.....	1
35	111934	Plate, heater element mounting.....	2
36	108352-07	Rivet, pop, 5/32" dia., 1/4" grip.....	20
37	111932	Cord, power, with Gravity Rack System (120V or 240V Warmer).....	1

**IMPORTANT:** Always provide Serial No. when ordering parts.

**NOTE:** Switch light is on whenever switch is on -- even if fuse blows.



Refer to reverse side of sheet for parts illustration.

SICO INCORPORATED  
 P.O. Box 1169  
 Minneapolis, Minnesota 55440, USA  
 Phone: (952) 941-1700  
 FAX: (952) 941-6688  
 Customer Service: 1-800-328-6138  
 SICO Inc. reserves the right to substitute materials or make changes, if materials are not available or such changes improve the product.

Also includes heater element,  
element cover, thermostat, etc.

