



SICO AMERICA INC.
7525 Cahill Road
Minneapolis, MN 55439, USA
Customer Service: 1-800-424-0796
Website: www.sicoinc.com

2-Tier Catering Table Operating Instructions

Note:

If problems or questions arise, contact SICO America Inc. customer service at the addresses or numbers listed at the bottom of this page.

Note: *Always provide the serial number when ordering parts or requesting technical assistance.*



Caution: *Always lock the locking casters when the 2-Tier Table is in use.*




Caution: *To avoid injury, never stand or sit on the 2-Tier Table top.*



Caution: *When moving the 2-Tier Table, always make sure that the pathway is visible and clear of obstructions.*


Locking a Caster

Press downward on the caster lock to lock a caster.



Lock the Table Top

To prevent the table top from folding, temporarily lock the top by hand or permanently lock with a 5mm hex wrench and tighten the lock as shown in the photographs at the right.



Moving the 2-Tier Table

Always push from the end of the table.



- Always push from the end of the table while making sure that the pathway is clear of obstructions.
- The 2-Tier Table can be moved with the table top vertical or horizontal.
- Avoid moving the table over uneven surfaces when set up.
- Two people should work together when moving the table up or down steep inclines.

FOLDING THE 2-TIER TABLE TO STORAGE POSITION

1. Ensure casters are in locked position before folding the table. (Figure 1.)



2. Collapse upper tier by pressing down on the yellow thumb screw, disengaging the auto-lock mechanism. Firmly grasp the upper tier and slowly lower to collapsed position. (Figure 2.)

NOTE: Do not fold main surface with tier in upper position, damage to table and/or injury may result.



3. Fold main surface to storage position. Unlock casters before moving the table. (Figure 3.)

