



SICO AMERICA INC.  
7525 Cahill Road  
Minneapolis, MN 55439, USA  
Customer Service: 1-800-424-0796  
Website: [www.sicoinc.com](http://www.sicoinc.com)

**Food Warmer**  
**Model No. 4918-700 (120V)**  
**Model No. 4918-800 (240V)**

# PARTS LIST

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty</u>
1	121081	Box, less door, with handles & latch	1
1	121081B	Box Black, less door, with handles & latch	1
2	121082	Door (with hinge)	1
2	121082B	Door Black (with hinge)	1
3	109501-05	Rivet, pop, 1/8-inch dia.,	8
4	112922	Shelf	3
5	112924	Latch	1
6	109505-08	Rivet, pop, 5/32" dia., #52	26
7	121143	Handle, side	2
9	108352-01	Handle, top	1
11	109501-04	Cover, element	1
14	108274-100	Element, 120V	1
14	108274-200	Element, 240V	1
18	109500-02	Thermostat	1
21	109500-10	Screw, Phillips sheet-metal, #8 x 3/8"	4
22	281231-700	Panel assembly, back, 120V (complete with element, etc.)	1
22	281231-700B	Panel assembly, back, 120V, BLACK (complete with element, etc.)	1
22	281231-800	Panel assembly, back, 240V (complete with element, etc.)	1
22	281231-800B	Panel assembly, back, 240V, BLACK (complete with element, etc.)	1
23	110079	Plug/switch combination	1
24	110078	Holder, fuse	1
25	109500-07	Fuse, 250V 3A, GMA 5 x 20 mm	1
26	112921	Screw, Phillips, 10-24 x 1-1/4"	4
28	108278	Cord, power (120V Warmer)	1
28	109519	Cord, power (240V Warmer)	1
34	112923	Washer, CSK, #10	4
35	111934	Plate, heater element mounting	2
36	108352-07	Rivet, pop, 5/32" dia., #56	8
37	111932	Cord, power, with Gravity Rack System (120V or 240V Warmer)	1
38	120545	Rivet, pop, 5/32" #54	4

**IMPORTANT:** Always provide the serial number when ordering parts.

**Note:** Switch light is on whenever switch is on — even if fuse is blown.

⚠ ADVERTENCIA ⚠ ⚠ WARNING

<p>Desconecte la unidad antes de lavarla</p> <p>Remueva el panel trasero antes de lavar el gabinete</p> <p>Dentro de la superficie puede estar caliente</p> <p>No roce o ponga líquidos en el gabinete o en el panel trasero</p> <p>Esto podría dañar los componentes eléctricos o mojar la insulación causando molde</p>	<p>Unplug Unit before servicing</p> <p>Remove rear panel before washing cabinet</p> <p>Inside surfaces may be HOT</p> <p>Do not spray liquids into cabinet or back panel. This could damage electrical components or dampen insulation causing mold</p>
---	---

108800  
REV. B

UNIT REACHES MAXIMUM TEMPERATURE IN **20** MINUTES.

**Refer to the reverse side of this page for the parts illustration.**

**Model No. 4918-700: 120V, 1.25 AMPS, 300 WATTS**  
**Model No. 4918-800: 240V, 2.5 AMPS, 300 WATTS**

**Cleaning:**

- Clean with a damp cloth and mild detergent solution or window cleaner, wiping in the grain direction.
- Do not use abrasives, scrapers, or cleaners containing chlorine.
- Rinse with a wet cloth, and dry with clean cloth.
- Scratches can be blended with a fine 3M Scotch Brite® pad, wiping in the grain direction.

SICO America Inc. reserves the right to substitute materials or make changes if materials are not available or such changes improve the product.

Also includes heater element,  
element cover, thermostat, etc.

